


Illus.	Part		l Illus.	Part		l IIIus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1		Literature Parts		4440454	Screw, 8/32 x 7/16	22	0700077	Deflector Vant
•	8303655		6 7		Top, Chassis	33		Deflector, Vent
	000000	Instructions	8		Screw, 6–32 x 1/2	34		Vent, Center Ext–Filler
		Use & Care Guide	9		Tube, Vent	35 37		
	8304080	Microwave	10		Lens, Light	37	9759243	Thermostat (TOD)
	8304079		11			42	0750740	(Temp.) SPST
	000 107 0	Cooking Guide	12		Oven Light Assy Bulb, Light	43		Base, Chassis
		(Label)	13			49		Retainer, Gasket
	8300348	` ,	13		Screw, 8–18 x 3/8 Frame, Front	50	4451747	Cover, Back
		Microwave	15			51	0000047	Trim, Bottom
		Tech Sheet (Oven)	16		Gasket, Door		8302947	
		Safer Cooking Tips	17		Spacer, Foam Insulation.		8302948	
	9759133	Safer Cooking Tips	''	4452337	Bottom Vent		8302949	
		Cookbook	19	1151170		F-0		Stainless Steel
2		Trim, Side	21	4451476	Support, Insulation Rail, Side	52		Vent, Control
_	8302927	RH Black	41	0202117		53		Chassis, Back
		RH White			Right Side Left Side		4452152	Bracket, Mounting
		RH Biscuit			Grommet		4450400	Bottom Trim
		RH Stainless Steel	22		Screw (3)	54		Insulation, Top
		LH Black	22 23	4449040		55	4452491	Insulation, Grill
		LH White	23	4450038			50110 1	WILL DADTO
		LH Biscuit	25		Side, Chassis			VING PARTS
		LH Stainless Steel	23	4455641	(R.H. & L.H.)		NOT ILL	.USTRATED
3	00002.0	Hinge, Receiver	26	4452234				
Ū	4455605	Left Hand	27	4452234	Liner. Oven			
		Right Hand	41		- ,	INSU	JLATION	
4		Bumper, Door	29	4455636	(Not Serviceable)		-	
5		Screw, 8–18 x 3/8	30		Bracket, Support		4449316	Insulation, Wrap
•		55.5, 5 10 X 0/0	30	4449045	Bracker, Support		4450365	Insulation, Back
			l			I		

CONTROL PANEL PARTS




No.	No.	DESCRIPTION			
1		Control Panel			
	8302848	Black			
	8302877	Stainless Steel			
	8302849	White			
	8302850	Biscuit			
2		Assy, Membrane			
	8303184	Black			
	8303226	White			
	8303232	Biscuit			
3	3400832	Screw			
4	4451592	Filter			
5	4452260	Spacer, Foam			
6	4451632	•			
7	8303491	Assy, Control			
8	4449745				
9	4449809	Screw, 8-18 x 3/8			
10	8303119	•			
11	3400832	,			
12	8304164	Backer, Control			
. —	0001101	Daonor, Common			

OVEN DOOR PARTS


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7	9760577 9760578 4449259 4451722 4457132	L.Side Glass, Inner Insulation, Door And Bottom Door Retainer, Glass Screw, 8–16 x 1/2	8 10 12 13	9759225 8303301 8303307	White Model Stainless Steel Biscuit Model Door Handle Black White Biscuit	14 15 16 18 19 22	9759229 9759230 8303810 4457103	Bracket, Handle Bracket(2nd Glass) Bracket(3rd Glass) Nameplate Shield, Heat Shield, Heat (Btm)

LATCH PARTS




Illus.	Part	
No.	No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4451758	Seal, Foam
3	8300791	Bracket, Combo
		Chassis
5		Screw, 8-18 x 3/8
9	4450408	Baffle, Rear
10	9759525	Latch Assy.
16	4452003	Blower
17		Vent, Top
18	4455177	Vent, Bottom

INTERNAL OVEN PARTS



llus.	Part	
No.	No.	DESCRIPTION
1	4448988	Cover, Fan
2	4456103	Element, Broil
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	4449154	screw
6		Rack, Oven
		Pad, Rack
7	4452153	Element, Bake
8	4452227	Nut
9	4451583	Convection Motor
10	4452226	Fan Blade
11	3181534	Rack, Roasting

CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

For Models:GSC308PRB01, GSC308PRQ01, GSC308PRT01, GSC308PRS01 (Black) (White) (Biscuit) (Black Stainless)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
	4075000	D 1 1 0 "				10		0 % 1 11 11
1		Bracket, Capacitor	29		Motor, Blower	42		Switch Holder
3		Rubber Ring	30	4375279	Thermostat		4375335	
4	4375038	Screw	31	4375079	Thermostat		4375336	Right
5	4375314	Air Duct,	34	4375286	Transformer	43	4375337	Isolation Plate
		Magnetron	35		Hinge, Door	44	4375338	Cover Plate
11	4375315	Damper		4375323		45	4375339	Door Plate
12	4375260	Duct, Inlet		4375324		46	4375340	Inner Frame
13		Insulation, Switch	36		Torison Spring	47		Side Plate
14		Fan Wheel			Black Stainless		4375341	Left
15		Duct, Air		02000	Model		4375342	
16		Block, Side	37		Bracket, Hinge	48		Turntable
17		Cover Plate, Upper	"	4375327		49		Ring Assembly
19		Lens, Lamp		4375328		50	4375345	
20	4375319		38	4375329	9	51	4375346	
21		Reflector	39		Door Strap	52		Motor, Turntable
25		Capacitor	40		Fan Cap	53	4375348	
26		Magnetron	1			54	4375349	
	4375321		41	4375334	Fan Cap Bottom			
27						55	4375350	
28	43/5231	Block, Fuse				56		Lamp Holder
						57	4452220	Rack, Convection
			1					Microwave


IMPORTANT PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO – IT – YOURSELF REPAIRS OF MICROWAVE OVENS.

The U.S. Consumer Product Saftey Commission warns against do—it—yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.


STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

MICROWAVE COMPARTMENT PARTS




No.	Part No.	DESCRIPTION
5		Support Rails
	4452551	Right Side
	4452552	Left Side
6	4449809	Screw, 8-18 x3/8
11	4452548	Rear Channel

MICROWAVE DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
9 10 11 12 13 14	8303556 4450038 4449809 4451040 4449141	Glass, Middle Frame, Door Screw Screw, 8–18 x 3/8 Screw, 8–16 x 1/2 Bracket, Mounting Right Side Left Side	15 16		White Biscuit	17 18 24	8303810	3 White

TOP VENTING PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
110.	110.	DECORN HOR		110.	DEGORII HON	-110.	110.	DECORNI HOR
1 2		Cover, Top Baffle, Blower	9	4454949 4449154	Holder, Fuse Screw	15 16		Back, Control Cover, Top Rear
3		Blower	10	4454976	Fuse	17	4448664	
	4450920	1200rpm	11	4449868	Block, Terminal	18		Cover, Top Front
	6610168	45mm	12	4452559	Side, Combo	19		Plate, Cover
4		Plate, Mounting	13	4449809	Screw, 8-18 x 3/8	20	4451934	Suppressor
5	6610122	Transformer,	14		Side, Control Top	21		Duct, Exhaust
		(Lights)		4451597	Right	22	4455191	Plate, Service
6	4455038	Transformer,		4451598	Left	23	9752759	Relay, Double
		Control						Line Break
7	4450027	Bracket, Duct				24	4163291	Screw, 6-20 x 1/2
8	4449964	Grommet				25	4449154	Screw, 8-32 x 7/16

OPTIONAL PARTS

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
PAINT, TOUCH-UP (1/2oz.) 72017 White 261869 Cord Brown 72032 Black PAINT, SPRAY 350930 White 261900 Citrine White 830864 Black ADHESIVE 591014 Adhesive	No. No. DESCRIPTION SPLICING WIRES25FT. LENGTH 242828 Wire (12 Ga. 150 C Black) 242820 Wire(14 Ga. 150 C Black) 242821 Wire (14 Ga. 150 C Blue) 242822 Wire (14 Ga. 150 C Brown) 242830 Wire (14 Ga. 200 C Brown) 242823 Wire (14 Ga. 150 C Green)	FOLLOWING PARTS NOT ILLUSTRATED 4378944 Filler Kit (BI) 4378945 Filler Kit (Wh) 4378946 Filler Kit (Wh) 4378946 Filler Kit (AI) 814381 Kit, Pin Hinge 4448950 Screw, Installation WIRING HARNESS PARTS 8301909 Harness, Latch 8301921 Harness, Main 8303838 Harness,
Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)	242824 Wire (14 Ga. 150 C Orange) 242829 Wire (12 Ga. 150 C Red) 242825 Wire (14 Ga. 150 C Red) 242831 Wire (14 Ga. 200 C Red) 242826 Wire (14 Ga. 150 C White) 242827 Wire (14 Ga. 150 C Yellow) 242832 Wire (14 Ga. 200 C Yellow)	Main Filter 4450831 Grown (M/W) 4450800 Screw 4449809 Screw 4450950 Conduit, Combo 313438 Clip, Harness 4452222 Spacer, Harness 4454835 Tie, Cable 4452400 Ground Lead